

## Optimally supplied

Siedle Basic is typically installed in the In-Home bus. No additional line rectifier is required to operate the video indoor station. The standard supply for the door intercom system and a transformer are all that's needed. There are no special cabling requirements.

