

Entrance controller
EC 602-03 FR/IT/NL

200036356-00



Product description

Entrance controller in switch panel housing for code lock module COM 611-..., electronic key reading module ELM 6xx-... or fingerprint module FPM 611-...

Display-supported programming of integrated buttons, or by means of PC software via additional programming interface PRI 602-... Electronic evaluating circuit with 2 switching outputs, extendable to 8 with ECE 602-..., 2 control inputs for time-controlled access rights.

Specifications

| | |
|----------------------------|---------------------------------|
| Operating voltage: | 12 V AC |
| Operating current: | 150 mA |
| Contact type: | 2 changeover switches 24 V, 2 A |
| Ambient temperature: | 0 °C to +40 °C |
| Protection system: | IP 20 |
| Horizontal pitch (HP): | 6 |
| Dimensions (mm) W x H x D: | 107 x 89 x 60 |

Article information

| Article designation | Article description | Colour/Material | KG SAP article no. |
|---------------------|---------------------|-----------------|--------------------|
| EC 602-03 FR/IT/NL | Entrance controller | Black | B 200036356-00 |

Accessories

| Article designation | Article description | Colour/Material | KG | SAP article no. |
|---------------------|-------------------------------|-----------------|----|-----------------|
| ECE 602-0 | Entrance controller extension | Black | B | 200015970-00 |
| ZRCE 602-0 | Ribbon cable | Others | B | 200017875-00 |

Entrance controller
EC 602-03 FR/IT/NL

200036356

Page 2





Entrance controller
EC 602-03 FR/IT/NL

200036356

Page 3

| | | | |
|--------------------------------|---------------------------|--------|----------|
| EC 602-03 Entrance controller | Product information | 344 kB | Download |
| | Programming instructions | 440 kB | Download |
| EC 602-03 Entrance controller | Programming instructions | 433 kB | Download |
| | Programming instructions | 447 kB | Download |
| EC 602-... Entrance controller | Programming instructions | 446 kB | Download |
| | Declaration of Conformity | 534 kB | Download |
| | Programming instructions | 848 kB | Download |
| EC 602-03 Entrance controller | Programming instructions | 444 kB | Download |
| | Programming template | 403 kB | Download |
| | Additional information | 140 kB | Download |